
AUROMEX[®]

TECHNICAL INSTRUCTIONS

DATA SHEETS

DECORMEX EF100SX **HIGH EFFICIENCY ELECTROFORMING PURE GOLD PROCESS**

INTRODUCTION

The AUROMEX **DECORMEX EF100SX** is a newly developed high efficiency slight acidic gold process, specially designed to give a highly ductile, hard and coarse grained deposits at thickness in excess of 1.25mm (0.050 inches). This process is advantageous to many applications especially in decorating jewellery industries and ideal for electroforming purpose, for building up thick deposits where subsequent finishing is not required.

FEATURES

- * Bright, sparkling coarse grained finish deposits
- * Deposits are hard and highly ductile
- * Non-critical in operation and control
- * No accumulation of deleterious brightener decomposition products
- * Exceptional throwing and covering power
- * High Cathode Efficiency and good thickness distribution
- * Highly Economy

DEPOSIT PROPERTIES

Appearance	: Bright, sparkling coarse grained finish (Rich lemon yellow colour)
Deposit purity	: 99.9% up
Karat	: 24 Kt
Hardness	: 110 - 140 mHv20g
Deposit Density	: 18.7 - 19.0 g / dm ²
For 1 micro deposit	: 187 - 190 mgm / dm ²

P-1

AUROMEX[®]

CHEMICALS CORPORATION

UNIT NO. 2, 4/F., INTERNATIONAL PLAZA, 20 SHEUNG YUET ROAD, KOWLOON BAY, KOWLOON, H.K.

TEL: 2796 7238

FAX: 852-2796 7117

EQUIPMENT

- Tanks Polypropylene or PVC glass fiber reinforced tanks are suitable.
- Heater Heating is required and temperature regulation is essential. Therefore, thermostatic controlled immersion heater are recommended.
- Rectifier A standard D C power supply should be used with an ampere output capacity sufficient to meet the requirements of the plating operation. The power supply should be equipped with a voltmeter, ammeter and step less control for accurate regulation of the current.
- Filtration The solution should be filtered continuously through polypropylene or cotton cartridges to maintain clarity.
- Agitation Moderate to vigorous agitation is necessary to maintain uniform metal distribution. Jet Stream and mechanical agitation at 7-14 m/min may be used.
- Anodes Insoluble anodes should be used, platinised titanium anodes with an area sufficient to provide a maximum current density of 0.25A / dm² are recommended.

PLATING BATH PREPARATION :

AUROMEX DECORMEX EF100SX make up chemicals are supplied in unit form. Each unit contains all the necessary additives required to make 10 litres working solution. It does not contain gold.

The following instructions are for the preparation of 10 litres of solution.-

Material required :

Gold potassium Cyanide (68.3%)		293 gms.
Decormex EF100SX Make Up Salt	(Code 100190)	1.0 kg
Decormex EF100SX Make Up Brightener	(Code 100191)	100 mls.
Decormex EF100SX Acid Adjustment Solution	(Code 100195)	

Potassium Hydroxide

Make up Procedures :

1. Pour 6 litres of demineralised or distilled water into the clean plating tank.
2. Add in the 1.0 kgs **EF100SX** Make Up Salt , stir until completely dissolved and then
3. add the 100 mls **EF100SX** Make Up Brightener .
Check and adjust pH to 6.3 with **EF100SX** acid or 10% potassium hydroxide solution.
4. Dissolve the gold potassium cyanide in a separate quantity of demineralised or distilled water and then add to the above solution.
5. Stir and check the pH again. Adjust to pH 6.3 if necessary.
6. Dilute the solution to 10 litres with demineralised or distilled water. The solution is then ready to use.

OPERATING CONDITIONS :

	<u>UNIT</u>	<u>RANGE</u>	<u>OPTIMUM</u>
Metallic gold content	g/l	20 - 25	20
pH electrometric		5.8 – 6.7	6.3
Temperature		30 - 50	40
Cathode current density	A/dm ²	0.3 – 0.8	0.5
Density	Be	6 - 20	8
Anode : Cathode ratio		3:1 – 5:1	4:1
Agitation		moderate	moderate
Plating rate	µm/hour	50 - 65	60

BATH MAINTENANCE

Gold metal content of the solution should be maintained at the recommended concentration (20-25 g/l) by periodic additions of gold potassium cyanide 68.3%. Replenisher Brightener is supplied as a liquid in units of 100 mls. One unit contains all the necessary additives to be added with the appropriate quantity of gold salts corresponding to 100 grams of gold metal.

Replenishment should be based on regular analysis but under optimum operating conditions, **DECORMEX EF100SX** process deposit metal at the following rates

<u>Amp-min</u>	<u>Gold consumed</u>
820	100 grams

For every 100 grams gold replenishment (147 grams 68.3% PGC) add one units (100 mls) **DECORMEX EF100SX** Replenisher Brightener (Code 100198).

Conductivity : Specific gravity of the solution should be maintained between 6-20 baume. If for any reason excessive drag out occurs, and specific gravity of the solution drops below 12 Be conducting salt (Code 100199) should be added to the solution. For every 16 g/l addition of this conducting salt will increase 1 Be at 35°C.

pH adjustment : The pH of the solution will rise slowly during use and should be checked periodically. To lower the solution pH by addition of **Decormex EF100SX** Acid. To increase pH by addition of 10% potassium hydroxide solution.

PACKING :

DECORMEX EF100SX Make Up Salt	(Code 100190)	1.0 kg / unit
DECORMEX EF100SX Make Up Brightener	(Code 100191)	100 mls / unit
DECORMEX EF100SX Replenisher Brightener	(Code 100198)	100 mls / unit
DECORMEX EF100SX Conducting Salt	(Code 100199)	1 , 2 , 25 kgs / pack
DECORMEX EF100SX Acid Adjustment Solution	(Code 100195)	1 , 2 , 5 litres / pack